EchoPro[®] LR46

Pulse Radar Solids Level Transmitter



LR46-5321-84-00

Shown

Application

The intrinsicallty safe 26 GHz. pulse radar transmitter provides continuous level measurement up to 229.7' (70m) with a 4-20 mA analog and HART digital signal output, and is configured via its integral push button display module or WebCal software. The non-contact solids level sensor is intended for dry solid media including aggregates, grains, pellets, powders and building materials. Select this sensor for the most difficult process conditions with significant to extreme dust, and installation with an adjustable gimbal flange. For ease of installation, the parabolic antenna can be unclamped, inserted through the base of a riser, and reattached to the sensor. Typical applications include silos.

CIENCE

No.1 Bukit Batok Street 22 #01-01 Singapore

SCIGATE AUTOMATION (S) PTE LTD

Business Hours: Monday - Friday 8.30am - 6.15pm

Fax: (65) 6562 0588 Web: www.scigate.co



Features

Parabolic antenna delivers high power RF signal strength

Tel: (65) 6561 0488

Email: sales@scigate.com.sg

- Configuration via push button display or WebCal software
- Gimbal flange for easy positioning with the angle of repose
- LCD displays level in feet or meters with percent of span bar
- HART communication in point to point and multi-drop modes
- Optional display mode indicates the echo signal return curve
- Rugged 316L stainless steel antenna and process mount
- Fail-safe diagnostics with selectable signal fail-safe outputs
- Recognition, storage and rejection of false echo signal returns
- IP67 stainless enclosure with polycarbonate display window

Antenna Selection

The reflective parabolic antenna focuses the RF energy to narrow the beam and increase the signal strength. The sensor is offered in two antenna sizes including 8" (196mm) and 10" (246mm). The larger the antenna, the narrower the beam and the stronger the RF signal return. To select the appropriate antenna size, consider two variables; The measured span distance and the amount of dust within the span.





EchoPro[®] LR46

Pulse Radar Solids Level Transmitter



Specifications

Range:	12" to 229.7' (30cm to 70m)
Frequency:	26 GHz.
Accuracy:	± 15mm
Dead band:	12" (30cm)
Beam angle:	- 8_: 5°
	- 0_: 4°
Configuration:	Push button; WebCal® PC Windows®
	USB [®] 2.0; HART 7 (pending)
Memory:	Non-volatile
Display type:	LCD, dot matrix
Display units:	Feet and meters
Display bar:	Percent of span
Display graph:	Echo signal curve
Supply voltage:	21.6 to 26.4 VDC
Max. consumption:	22.5 mA
Signal output:	4-20 mA, two-wire, HART 7
Signal invert:	4-20 mA, 20-4 mA
Signal fail-safe:	3.9 mA, 20.5 mA, 22 mA
Process temp.:	F: -40° to 752°
	C: -40° to 400°
Temp. comp.:	Automatic
Storage temp.:	F: -40° to 176°
	C: -40° to 80°
Pressure:	Atmospheric
Enclosure rating:	IP67
Encl. material:	316L stainless steel w/silicone gasket
Encl. window mat.:	Polycarbonate
Conduit entrance:	(1) 1/2" NPT connector
Antenna material:	316L & PTFE
Process mount:	4: 4" gimbal flange (ANSI)
	5: 5" gimbal flange (ANSI)
Classification:	Intrinsically safe
Approvals (pending):	ATEX 🚱 II 1C Ex ia III C T76° CT146° C Da
	IEC Ex ia III C T76° CT146° C Da
	CSA Class I, Div 1, Groups A, B, C & D;
	Class II, Groups E, F & G; Class I Zone 0
	IIC & Zone 20 Group IIC
Certification:	FCC
Compliance:	CE, RoHS

LR46-5321-

Dimensions







Level Indicator

Echo Signal Return Curve



DATALOOP™ Intrinsically Safe Level Indicator

FM and CSA approved intrinsically safe, the loop powered level indicator displays engineering units connected in series with one 4-20 mA level transmitter. Select the LI25-2001 level indicator for hazardous applications with an intrinsically safe sensor. For field mount installation, add a single or two indicator NEMA box.

Ordering



- **8** 8" (196mm) parabola
- **0** 10" (246mm) parabola

MOUNT SIZE -

- 4 4" gimbal flange
- 5 5" gimbal flange

FOB USB ADAPTER (2)

- 0 Without Fob
- 1 With Fob

NOTES

- If you want help in selecting a sensor for your application, please go to our website and submit a Level Questionnaire. An engineer will review your requirements and suggest a product solution via email.
- Sensors are offered with or without a LI99-3001 Fob USB adapter. If you want to configure the sensor using our free WebCal software, you need one Fob, which can be used with any EchoPro sensor.

0